

PRODUCT SPECIFICATIONS

Maximum seating capacity:	4 adults
Water capacity:	210 gal (795 L)
Inner/outer diameter:	58/75 in (147/191 cm)
Height:	28 in (71 cm)
Bubble air blower:	0.9HP / 110-120 V / 60 Hz
Filter pump flow rate:	460 gal/hr (1,741 L/hr)
Heater power:	1,300 Watts / 110-120V / 60Hz
Temperature range:	68°F - 104°F (20°C - 40°C)
Temperature rise:	2-3°F/hr (1-1.5°C/hr)
Number of Bubble Jets:	120
Spa tub recommended working air pressure:	0.083 bar (1.2 psi)
Model SSP-10-1:	Cord-connected spa with pump, heater, blower and control panel.
Model SSP-H-10:	Cord-connected spa with pump, heater, blower, built-in hard water treatment and control panel.

SET UP

Site preparation and requirements

- The spa can be installed indoor or outdoor. For household use only.
- The spa must be set up on a level, flat and smooth surface that is capable of supporting the maximum load of the filled spa with four adult occupants; weight 2500 lbs (1136Kg).
- Make sure the area is free of sharp objects under or around the spa.
- Provide adequate drainage system around the spa to deal with overflow water and splashes.
- Provide a properly located power outlet to connect the spa and allow easy access for periodic testing of the cord mounted GFCI/RCD.
- Make sure there is enough clearance around the spa for full access to the spa equipment for maintenance and/or service.
- The area shall facilitate draining purposes during long term spa storage.

Additional requirements for indoor installation

- Make sure the floor can support the full weight of the filled spa with the maximum number of occupants. Check with a qualified contractor or a structural engineer to verify this requirement.
- Make sure the floor is water resistant and non-slip surface. Do not install the spa on carpet or other materials that will be damaged by moisture, condensation.
- Do not install the spa indoors on a second floor above finished living space due to the possibility of water and humidity damage.
- Humidity is a natural side effect of indoor spa installation. The room shall be properly ventilated to allow moisture to escape. Install a ventilating system to prevent excess condensation, moisture in the room.

Additional requirements for outdoor installation

- Spa owners may need to comply with local or states laws relating to childproof fencing, safety barriers, lighting, and other safety requirements. Contact your local building code enforcement office for further details.
- Make sure the surface is level, flat, smooth and strong enough to support the full weight of the filled spa.
- Do not setup the spa on grass or dirt, as this increases the amount of debris entering the spa, and damage the spa floor.
- Do not expose the spa to direct sunlight for extended period of time.
- It is possible to install and leave the spa outside at a temperature not lower than 39°F (4°C) provided the water temperature inside the spa is higher than 39°F (4°C) and the water inside the circulation system, pump, pipes are not frozen. Put a "temp barrier mat" between the spa floor and the ground to prevent heat loss from the bottom of the spa and to provide better heat retention.

SAVE THESE INSTRUCTIONS

Page 7

Learn more about Intex Recreation Corp, the leader in above ground pools, airbeds, and spas. Get support for your Intex products. Shop for above ground pools.FAQs - Pumps. Manual Pumps Electric Pumps. There are no FAQs. Newsletter Sign-Up. Join. Contact. Contact Us; () ; M-F AM - 5 PM PST.Search in INTEX catalogs and technical brochures on ArchiExpo and find the information you need ArchiExpo - The Online Architecture and Design Exhibition.View and Download Intex Ultra Frame owner's manual online. Ultra Frame Pool. Ultra Frame Swimming Pool pdf manual download.Don't forget to try these other fine Intex products: pools, pool accessories, . This product is intended to be used only for the purposes described in the manual!.Don't forget to try these other fine Intex products: Pools, Pool. Accessories, Inflatable which may result in updates to the instruction manual without notice.Appliance manuals and free pdf instructions. Find the user manual you need for your home appliance products and more at ManualsOnline.Find the user manual you need for your lawn and garden product and more at ManualsOnline. Intex Recreation Swimming Pool Manuals. Showing Products 1.user manual you need for your home appliance products and more at ManualsOnline. Intex Recreation Krystal Clear Filter Pump Water Pump User Manual.Find the user manual you need for your lawn and garden product and more at ManualsOnline. Intex Recreation HT Swimming Pool Heater User Manual.84 Instruction Manuals and User Guides in category Sports and recreation for Intex online. Read online or download owner's manuals and user guides for.dqmonnaies.com: Intex Krystal Clear Sand Filter Pump for Above Ground Pools, inch, V with GFCI: Swimming Pool Sand Filters User Manual [pdf].22 Items Shop online or in-store for above ground, portable, inflatable and kids swimming pools and accessories at the best prices. Clark Rubber for everything.pump flow rate v with gfcI swimming pool water view and download intex sf owners manual online krystal clear sand filter pump 14 sfIntex Swimming Pool 14ft Rectangle is backyard pool inflatable pool & above It comes with repair kit and instruction manual for easy installation.Citation Machine helps students and professionals properly credit the information that they use. Cite sources in APA, MLA, Chicago, Turabian, and Harvard for.

- [\[PDF\] cost of adobe fireworks cs5](#)
- [\[PDF\] suburban manual trans](#)
- [\[PDF\] coby dp151 photo viewer software](#)
- [\[PDF\] casio lk-30 note lighted keyboard](#)
- [\[PDF\] sound loop s](#)
- [\[PDF\] deltalab dgfx1 manual](#)
- [\[PDF\] remington ms3-1000 rechargeable shaver](#)